

This article is available online at:

<http://www.cybernetman.com//kb/index.cfm/fuseaction/home.viewArticles/articleId/231>

Add Multitouch Functionality to the ZPC TouchPad

To enable multi-touch functionality on the ZPC-series touchpad, download the driver package (Synaptics_Touch_Driver.zip) from our ftp site and extract the files. This new driver is compatible with 32-bit and 64-bit versions of Windows XP, Windows Vista, and Windows 7.

1. Begin by uninstalling the current touchpad driver through the Add/Remove Programs section of the Control Panel (Programs and Features for Vista/7).
 2. If there is no listing for a Synaptics touch device then simply install the new driver.
 3. Otherwise uninstall the Synaptics touch device and restart the computer.
 4. Upon restarting, locate the extracted driver files and run the included setup file.
 5. Upon completion, restart the computer.
 6. To set up the new functions, go back to the Control Panel and open up the Mouse properties.
 7. Tab over to the Synaptics tab (labeled Device Settings) and click the Settings button to be presented with the Properties window below. The new features are highlighted in red.
-

Properties for Synaptics TouchPad



Select an item

- [-] Overview
- [-] Scrolling
 - [-] One-Finger Scrolling
 - [-] Two-Finger Scrolling
- [-] Pointing
- [-] Buttons
 - Scroll Up Button Action
 - Scroll Down Button Action
 - Scroll Left Button Action
 - Scroll Right Button Action
 - Left Button Action
 - Right Button Action
- [-] Tapping
 - Tap and Drag
 - [-] Tap Zones
- [-] Application Gestures
 - [-] Three-Finger Press
 - [-] Three-Finger Flick



This **Properties** window allows you to personalize your pointing device settings. Use the menu tree to the left to access the customizable features. These include single-finger pointing and scrolling options, plus multi-finger gestures to manipulate documents, objects, and applications.

Using the Properties Window
Click on a feature in the menu tree to see a page of descriptions and settings for that feature. Some features have several pages of settings. Click on the + (plus sign) next to a feature to see all its related pages. The settings will appear in the window to the right of the menu tree. Information about these options and instructions on how to change them will appear here in this information box. You can use the scroll bar to view the

Defaults

www.synaptics.com

OK

Cancel

Apply